Extraflame®

Riscaldamento a Pellet

COMFORT P70 & P70 H49
INSERT USER MANUAL

ENGLISH/INGLESE

We thank you for having chosen our company; our product is a great heating solution developed from the most advanced technology with top quality machining and modern design, aimed at making you enjoy the fantastic sensation that the heat of a flame gives, in complete safety.

Extraflame S. p. A.

ENGLISH 4

WARNINGS **4**
SAFETY **4**
ROUTINE MAINTENANCE **4**
SAFETY DEVICES **5**
REFERENCE STANDARDS **5**
GENERAL 6
INSTALLATION **7**
FUMES EXHAUST SYSTEM **8**
GENERAL REQUIREMENTS 8
SMOKE DUCT 9
CHIMNEY 11
CHIMNEY CAPS 11
FUMES EXHAUST SYSTEM PRODUCT REQUIREMENTS 12
COMBUSTION PRODUCTS OUTLET QUOTA 12
TECHNICAL INSTALLATION DOCUMENTATION 13
COMFORT P70/ P70H49 INSTALLATION **14**
MINIMUM DIMENSIONS 14
AIR CIRCULATION PIPES **15**
ASSEMBLY WITH SLIDING BASE 17
PEDESTAL ASSEMBLY (OPTIONAL): **17**
MOUNTING THE FRAMES **18**
REMOVING THE INSERT AND LOADING PELLETS **19**
PELLETS **20**
FRONT PELLET FEEDING KIT (OPTIONAL) **20**
CONTROL PANEL **21**
DISPLAY ICONS KEY 21
GENERAL MENU **22**
BASIC INSTRUCTIONS 22
THE REMOTE CONTROL **23**
DELAYED SWITCH-OFF ENABLING 23
TYPE AND REPLACEMENT OF BATTERIES 23
COMMISSIONING SETTINGS **24**
ADJUSTING TIME, DAY, MONTH AND YEAR 24
ADJUSTING LANGUAGE 24
OPERATION AND LOGIC **25**
ADDITIONAL THERMOSTAT (OPTIONAL) **26**
USER MENU **26**
DISPLAY 26
PELLET FEED ADJUSTMENT 26
V1- AIR 27
STAND BY 27
KEYS LOCKED 28
V2 - AIR 29
RESET 29
CHRONO **29**
PROGRAMMING EXAMPLE 30
CLEANING UNDER USER'S RESPONSIBILITY **31**
ROUTINE MAINTENANCE **33**
DISPLAYS **34**
ALARMS **35**
WARRANTY CONDITIONS **36**

INDEX

WARNINGS

This instructions manual is an integral part of the product: make sure that it always accompanies the appliance, even if transferred to another owner or user, or if transferred to another place. If it is damaged or lost, request another copy from the area technician. This product is intended for the use for which it has been expressly designed. The manufacturer is exempt from any liability, contractual and extracontractual, for injury/damage caused to persons/animals and objects, due to installation, adjustment and maintenance errors and improper use.

Installation must be performed by qualified staff, which assumes complete responsibility for the definitive installation and consequent good functioning of the product installed. One must also bear in mind all laws and national, regional, provincial and town council Standards present in the country in which the appliance has been installed.
Extraflame S.p.A. cannot be held responsible for the failure to comply with such precautions.

After removing the packaging, ensure that the content is intact and complete. Otherwise, contact the dealer where the appliance was purchased.
All electric components that make up the product must be replaced with original spare parts exclusively by an authorised after-sales centre, thus guaranteeing correct functioning.

SAFETY

- The stove must not be used by persons (including children) with reduced physical, sensory and mental capacities or who are unskilled persons, unless they are supervised and trained regarding use of the appliance by a person responsible for their safety.
- Children must be checked to ensure that they do not play with the appliance.
- Do not touch the stove when you are barefoot or when parts of the body are wet or damp.
- The safety and adjustment devices must not be modified without the authorisation or indications of the manufacturer.
- Do not pull, disconnect, twist electric cables leaving the stove, even if disconnected from the electric power supply mains.
- It is advised to position the power supply cable so that it does not come into contact with hot parts of the appliance.
- The power supply plug must be accessible after installation.
- Do not close or reduce the dimensions of the airing vents in the place of installation. The airing vents are essential for correct combustion.
- Do not leave the packaging elements within reach of children or unassisted disabled persons.
- The hearth door must always be closed during normal functioning of the product.
- When the appliance is functioning and hot to the touch, especially all external surfaces, attention must be paid
- Check for the presence of any obstructions before switching the appliance on following a prolonged period of inactivity.
- The stove has been designed to function in any climatic condition (even critical). In particularly adverse conditions (strong wind, freezing) safety systems may intervene that switch the stove off. If this occurs, contact the technical after-sales service and always disable the safety systems.
- In the event the flue catches fire, use suitable systems for suffocating the flames or request help from the fire brigade.
- This appliance must not be used to burn waste
- Do not use any flammable liquids for ignition
- During the filling phase do not put the bag of pellets to into contact with the product
- The majolicas are top quality artisan products and as such can have micro-dots, crackles and chromatic imperfections. These features highlight their valuable nature. Due to their different dilation coefficient, they produce crackling, which demonstrate their effective authenticity. To clean the majolicas, it is recommended to use a soft, dry cloth. If a detergent or liquid is used, the latter could penetrate inside the crackles, highlighting them.

ROUTINE MAINTENANCE

Based on Decree 22 January 2008 n°37 art.2, routine maintenance means interventions aimed at reducing degradation due to normal use, as well as dealing with accidental events entailing the need of first interventions, which however do not modify the structure of the system upon which one is intervening or its intended use according to the requirements laid down by the technical standards in force and by the manufacturer's use and maintenance manual.

SAFETY DEVICES

SAFETY DEVICES KEY: * = PRESENT, - = NOT PRESENT	STOVES
Circuit board: it intervenes directly sending the product into alarm conditions until it has fully cooled down, in the event of: fumes motor breakage, pellet feed motor breakage, black out (if above 10 seconds), failed ignition	*
Door micro switch: With the door open, the operation of the burn pot cleaning system is blocked	-
Electronic pressure switch: in the event of inadequate depression, it sends the machine in alarm conditions	*
F 2.5 A 250 V fuse (stoves): protects the machine from violent current surges	*
85°C calibrated mechanical bulb with manual rearm: intervenes by blocking fuel feed whenever the pellet tank t° reaches the limit of 85°C. **Rearm must be performed by qualified staff and/or the manufacturer's technical after-sales assistance.**	*
Pellet tank temperature control probe: if the tank over-heats, the machine automatically modulates to return to normal temperature values (* in the applicable models)	*
Mechanical air pressure switch: blocks the pellet in the event of insufficient depression (in the relevant models)	*

REFERENCE STANDARDS

The installation must be in compliance with:

- **UNI 10683 (2012) heat generators fed with wood and other solid fuels: installation.**

The chimneys must be in compliance with:

- UNI EN 13063-1 and UNI EN 13063-2, UNI EN 1457, UNI EN 1806 in the event of non-metallic chimneys:
- EN 13384-1 (13384) chimneys. Thermal and fluid dynamic calculation methods.
- UNI EN 1443 (2005) chimneys: general requirements.
- UNI EN 1457 (2012) chimneys: clay/ceramic flue liners.
- UNI/TS 11278 (2008) Metal - chimneys/flue liners/flue ducts.
- UNI 7129 point 4.3.3 Fire Brigade provisions, local rules and regulations.

NATIONAL, REGIONAL, PROVINCIAL AND TOWN COUNCIL REGULATIONS

One must also bear in mind all laws and national, regional, provincial and town council Standards present in the country in which the appliance has been installed.

TERMS AND DEFINITIONS

Aeration: Air renewal is required both for the disposal of the combustion products, and to prevent mixtures with a hazardous content of non-combusted gases.

Closed hearth appliance: Appliance designed for operation with closed combustion chamber.

Forced draught appliance: Appliance with ventilation in the fumes circuit and combustion with fumes flow at a positive pressure with respect to the environment.

Chimney: Structure consisting in one or several walls containing one or several outflow airways.
The purpose of this predominantly vertical element is to expel the combustion products at a convenient height from the ground.

Smoke duct: Component or components that connect the outlet of the heat generator to the chimney.

Chimney cap: Device that placed on the chimney outlet allows the dispersion of the combustion products even in presence of adverse weather conditions.

Condensation: Liquid products which form when the fumes temperature is lower or equal to the water dew point.

Ducting pipe: Pipe made up of one or several predominantly vertical elements, specifically suitable for collecting and expelling the fumes, as well as to withstand the relative components and any condensate over time,
suitable to be installed in a chimney, existing or new technical compartment, even in new buildings.

Sealed installation: Installation of an appliance with sealed operation, so that all the air required for combustion is taken from outside.

Maintenance: Set of procedures required to ensure and maintain safety and functionality over time and maintain the efficiency of the system within the prescribed parameters.

Chimney system: Chimney installed using a combination of compatible components, manufactured or specified by a sole manufacturer whose product liability covers the entire chimney.

Fumes exhaust system: Flue gas exhaust system, independent from the appliance made up of a smoke duct, chimney or individual flue and chimney cap.

Radiation area: Area immediately in front of the hearth in which the radiant heat caused by combustion is diffused.

Reflux area: Area beyond the extrados of the roof in which overpressure or depressions occur, which may affect the proper discharge of the combustion products.

FUNCTIONAL OPERATIONS DIAGRAM

State of the art installation and proper system operation include a series of activities:

1. Preliminary activities:

- verification of the suitability of the installation site,
- verification of the suitability of the fumes exhaust system,
- verification of the suitability of the outside air inlets;

2. Installation:

- implementation of ventilation and connection to the outer air inlets,
- implementation and connection to the fumes exhaust system,
- assembly and installation,
- electric and hydraulic connections,
- installation of insulation,
- ignition and operation test,
- installation of finishings and coverings;

3. Issue of complementary documentation;

4. Inspection and maintenance.

Other actions may be required in relation to specific requests of the competent authority.

PRELIMINARY ACTIVITIES

GENERAL

Verification of compatibility of the system, of any restrictions required by local administrative regulations, special or conventional requirements resulting from condominium regulations, constraints, laws or administration deeds must precede any other assembly or installation operation.

One must especially verify the suitability:

- of the installation premises, of the appliances already installed in the installation premises and in the adjacent and adjoining premises, also powered by different fuels, with particular reference to non-compliant installations.

- of the fumes exhaust system
- of the outside air inlets

SUITABILITY OF THE FUMES EXHAUST SYSTEM

Installation must be preceded by a compatibility test between the appliance and the fumes exhaust system, by verifying:

- the existence of documentation relating to the system;
- existence and content of the chimney plaque;
- suitability of the internal section of the chimney;
- absence of obstructions all along the chimney;
- predominantly vertical height and development of the chimney;
- existence and suitability of the chimney cap;
- distance of the outside wall of the chimney and of the smoke duct from
- combustible materials;
- chimney type and material;
- absence of other chimney connections.

INSTALLATION

Installation in premises with fire hazards is forbidden. Installation in residential premises (except for sealed operation appliances) is also forbidden:

- in which there are liquid fuel-operated appliances with continuous or intermittent operation, which draw the combustion air in the room in which they are installed, or
- in which there are type B gas appliances intended for room heating, with or without production of domestic hot water and in adjacent and adjoining premises, or
- in which, in any case, the depression measured during installation between the internal and external environment is greater than 4 Pa

Installations in bathrooms, bedrooms and studio flats

Installation in bathrooms, bedrooms and studio flats is only allowed for sealed or closed hearth appliances with ducted combustion air taken from the outside.

Installation premises requirements

The support surfaces and/or points must have a suitable load-bearing capacity to support the weight of the appliance, of the accessories and coatings.
The adjacent, side and rear walls and the supporting surface must be made of non-combustible material according to the table

REFERENCES	INFLAMMABLE OBJECTS	NON-INFLAMMABLE OBJECTS
A	200 mm	100 mm
B	1500 mm	750 mm
C	200 mm	100 mm



figure 1



figure 2

In any case the temperature of the adjacent combustible materials must not reach a temperature equal to or greater than the room temperature increased by 65°C.

The minimum volume of the premises in which to install the appliance must be greater than 15 m^3.

VENTILATION AND AERATION OF THE INSTALLATION PREMISES

Ventilation is deemed sufficient when the room is equipped with air inlets according to the table:

Air inlet
See figure 2

Appliance categories	Reference standard	Percentage of the net opening section with respect to the appliance fumes outlet section	Minimum net opening value of the ventilation duct
Pellet stoves	UNI EN 14785	-	80 cm^2

In any case ventilation is deemed sufficient when the pressure difference between the external and internal environment is equal to or less than 4 Pa.

In the presence of type B gas appliances with intermittent operation not intended for heating, they must have their own aeration and/or ventilation opening. The air inlets must meet the following requirements:

- they must be protected with grids, metal mesh, etc., but without reducing the net useful section;
- they must be made so as to make the maintenance operations possible;
- positioned so that they cannot be obstructed;

The air flow can also be obtained from a room adjacent to that of installation (indirect aeration and ventilation), as long as the flow takes place freely through permanent openings communicating with the outside.
The adjacent room cannot be used as a garage, warehouse of combustible material or for any other activity with a fire hazard, bathroom, bedroom or common room of the building.

FUMES EXHAUST SYSTEM

GENERAL REQUIREMENTS

Each appliance must be connected to a suitable fumes exhaust system and ensure adequate dispersion of the combustion products into the atmosphere. The combustion products must discharged above the roof. Direct discharge from the wall or towards closed spaces is forbidden, even with clear skies.
In particular, it is forbidden to use flexible and extendible metal pipes.
The chimney should only receive the exhaust of the smoke duct connected to the appliance; collective flues or conveying exhausts from hoods above cooking appliances of any kind, or exhausts from other generators into the chimney itself or smoke duct are not allowed.
The smoke duct and the chimney must be connected with a continuity solution, in order to prevent the chimney from resting on the appliance.
It is forbidden to have other air supply channels and pipes for plant engineering transit inside the fumes exhaust systems, especially if over-sized.

The components of the fumes exhaust system must be chosen in relation to the type
of appliance to be installed in compliance with:

- in the event of metal chimneys, UNI/ TS 11278, with particular attention to what is stated in the specification;
- in the event of non-metallic chimneys: UNI EN 13063-1 and UNI EN 13063-2, UNI EN 1457, .-UNI EN 1806;

Considering especially:

- temperature class;
- pressure class (fumes seal) at least equal to the seal required for the appliance;
- moisture resistance (resistance to condensation);
- class or level of corrosion and specification of the materials constituting the inner wall in contact with the fumes.
- soot fire resistance class;
- minimum distance from combustible materials

The installer of the fumes exhaust system, once the installation is complete and the relevant checks and inspections have been made, must fix the chimney plaque supplied by the manufacturer with the product in a visible manner, near the fireplace, and which must be completed with the following information:

- nominal diameter;
- distance from combustible materials, indicated in millimetres, followed by the arrow and flame symbol;
- installer data and date of installation.

Every time one must cross combustible materials, the following indications must be complied with:



SYMBOL	DESCRIPTION	QUOTA[MM]
b	Minimum distance of combustible materials from the intrados of the framework/floor/wall	500
b.1	Minimum distance of combustible materials from the extrados of the framework/floor	500
a	Minimum distance from combustible materials defined by the manufacturer	G(xxx)
The single wall pipes are indicated in white. The insulated double wall chimney systems are indicated in grey.		
One can disregard the quota only in the event of using an appropriate heat protection screen (for example: wall plate) to protect the intrados of the framework/floor		

SMOKE DUCT

General requirements

The smoke ducts must be installed in compliance with the following general requirements:

- they must be insulated if they cross through rooms that are not to be heated or outside the building;
- they must not cross rooms in which the installation of combustion appliances is forbidden, nor in other premises compartmentalised against fire or with a fire hazard, nor in rooms and/or areas that cannot be inspected;
- they must be installed so as to allow normal thermal expansion;
- they must be fitted to the opening of the chimney without protruding inwards;
- the use of flexible metal pipes to connect the appliance to the chimney is not allowed;



- counter-slope sections are not allowed;
- the smoke ducts must have, along their entire length, a diameter that is no less than that of the attachment of the appliance exhaust pipe; any section changes are allowed only on the inlet to the chimney;
- they must be installed so as to limit the formation of condensation and prevent their release from the joints;
- they must be positioned at a distance no less than that indicated in the product specifications from combustible materials;
- the smoke channel/duct must allow to collect the soot and to be cleaned using a swab and inspected after being disassembled, or through inspection openings when not accessible from inside the appliance.

ADDITIONAL REQUIREMENTS FOR APPLIANCES FITTED WITH AN ELECTRIC FAN FOR FUMES EXPULSION

For the heat generator appliances equipped with electric fan for expelling fumes, the instructions below must be followed:

- The horizontal sections must have a minimum upward slope of 3%
- The length of the horizontal section must be minimal and, in any case, no longer than 3 metres
- The number of direction changes including the one due to the use of the "T" element must not be more than 4.

EXAMPLES OF CORRECT CONNECTION TO THE CHIMNEY


Installation with internal flue
Protection from rain and wind
Insulated flue
Condensation-proof "T" fitting with inspection plug


Installation with internal - external flue
Protection from rain and wind
Insulated flue
Insulated condensation-proof "T" fitting with inspection plug

IT IS NOT RECOMMENDED TO INSTALL A 90° BEND AS THE FIRST INITIAL PART, SINCE THE ASH WOULD BLOCK THE PASSAGE OF THE FUMES IN A SHORT TIME, CAUSING PROBLEMS TO THE STOVE DRAUGHT. SEE FIGURES BELOW:





EXAMPLES OF CORRECT CONNECTION TO THE CHIMNEY


Protection from rain and wind
Steel plate, airtight
"T" fitting with inspection plug
Protection from rain and wind
Max 3 mt
3 - 5%
"T" fitting with inspection plug
Insulated "T" fitting with inspection plug

It is mandatory to use airtight pipes.

CHIMNEY

In addition to the general requirements, the chimneys for releasing combustion products into the atmosphere must:

- operate under negative pressure (operation under positive pressure is not allowed);
- have a preferably circular internal section; square or rectangular sections must have rounded corners with a radius of no less than 20 mm (hydraulically equivalent sections may be used, as long as the ratio between the longer side and the shorter side of the rectangle, which circumscribes the section, is in any case no greater than 1.5);
- be designed for fumes be designed for fumes expulsion;
- be predominantly vertical and have no narrowing along their entire length;
- have no more than two direction changes with a slope angle no greater than 45°;
- be fitted with, in the event of operating in damp conditions, a device for reflux drainage (condensation, rainwater);

Ducted system

A ducted system can be installed with one or more ducts, operating only with negative pressure with respect to the environment.

The flexible hose compliant with UNI EN 1856-2, with T400-G characteristics, meets the requirements.

CHIMNEY CAPS

The chimney caps must meet the following requirements:

- they must have a useful outlet section no less than double of that of the chimney/ducted system on which it is installed;
- they must be adapted in order to prevent the penetration of rain and snow in the chimney/ducted system;
- they must be built so that, in the event of winds coming from all directions and from any angle, the expulsion of combustion products is in any case ensured;
- they must be free from mechanical intake aids.

COMBUSTION PRODUCTS OUTLET QUOTA

The outlet quota is determined by measuring the minimum height between the roof covering and the lower point of the fumes expulsion section into the atmosphere; this quota must be outside the reflux area and at an adequate distance from obstacles which hinder or make the expulsion of the combustion products difficult or from openings or accessible areas.

Reflux area
The outlet quota must be outside the reflux area calculated according to the indications below.
Near the ridge one considers the lowest between the two.

Buffer area for outlet quota



Clear area for outlet quota above the roof slope (β >10°)

REFERENCE	DESCRIPTION	CLEAR AREA (MM)
c	Distance measured at 90° from the roof surface	1300
a	Height above the ridge of the roof	500

The outlet of a chimney/ducted system must not be near obstacles that may create turbulence areas and/or prevent proper expulsion of combustion products and maintenance operations to be carried out on the roof.
Verify the presence of other chimney caps or skylights and dormers.

FUMES EXHAUST SYSTEM PRODUCT REQUIREMENTS

Temperature class

In the event of a pellet appliance, temperature classes below T200 are not allowed.

Soot fire resistance class

The fumes exhaust system interlocked with appliances supplied by solid fuels require soot fire resistance, and the specification must be indicated by the letter G followed by the distance from combustible materials in millimeters (XX) (in compliance with UNI EN 1443) .

In the event of pellet appliances, the fumes exhaust systems must be airtight; if double designation elements are used (G and O, with or without seal elastomer) for connecting the appliance to the chimney, one must comply with the minimum distance XX in millimeters, indicated for designation G; in the event of fire due to soot, one must ensure the restoration of the initial conditions (by replacing the gaskets and damaged items and cleaning those remaining in use).

Ignition tests

Operation of the appliance must be verified with an ignition test, i.e.:

- for mechanical feed appliances, one must complete the ignition test, verify proper operation for at least the next 15 minutes and adjust the switch-off;

For appliances installed in a hot water heating system (closed fireplaces, thermo-stoves), testing must also extend to the entire hydraulic circuit.

Coverings and finishings

The coverings and finishings must only be applied after having verified the proper operation of the appliance according to the indicated modalities

TECHNICAL INSTALLATION DOCUMENTATION

When installation is complete, the installer must provide the owner or person acting for him, according to the legislation in force, with the declaration of conformity, supplied with:

1) the use and maintenance manual of the appliance and of the system components (such as for example, the smoke ducts, chimney, etc.);
2) photocopy or photograph of the chimney plaque;
3) system booklet (where applicable).

The installer must ask to be issued with a receipt stating that the documentation has been provided, and must keep it with a copy of the technical documentation relating to the installation.

Installation performed by several parties

If the individual installation steps are carried out by different parties, each must document the work carried out for the customer and the for the operator working on the next step.

INSPECTION AND MAINTENANCE

Frequency of operations
Maintenance of the heating system and of the appliance must be carried out on a regular basis according to the table below:

TYPE OF APPLIANCE INSTALLED	<15kW	(15- 35) kW
Pellet operated appliance	1 year	1 year
Water operated appliances (closed fireplaces, thermo-stoves, thermo-kitchens)	1 year	1 year
Boilers	1 year	1 year
Fumes exhaust system	4 t of fuel used	4 t of fuel used

For further details refer to the "cleaning and maintenance" chapter.

Inspection and maintenance report

At the end of the inspection and/or maintenance operations, a report must be issued and released to the owner, or person acting for him, who must confirm its receipt in writing. The report must indicate the situations encountered, the action taken, any components replaced or installed and any comments, recommendations and requirements.
The report must be kept with the relative documentation.

In the inspection and maintenance report one must mention:
- anomalies detected that cannot be removed, which pose a risk to the safety of the user or serious damage to building;
- components that have been tampered with.

If anomalies as per above were detected, the owner, or person acting for him, must be warned in writing, in the maintenance report, to refrain from using the system until the safety conditions have been fully restored.

The inspection and maintenance report must include the main information of the technician or company who performed the inspection and/or maintenance operations, with their contact details, date of intervention and the signature of the operator.

COMFORT P70/ P70H49 INSTALLATION

The insert is supplied with a sliding metal base that allows it to be installed in a pre-existing flue.
The sliding base allows the easy extraction of the insert both for feeding pellets into the feed-box and for any maintenance or cleaning at the end of the season. If there is no pre-existing flue, it can be built using the insert support pedestal (optional kit); in fact, the latter attaches the insert to the floor.

COMPONENTS DESCRIPTION:

A. Primary air intake pipe

B. Flue exhaust pipe

C. Adaptation frame

D. Sliding base and rails



MINIMUM DIMENSIONS

P70	P70H49
MINIMUM 570 X 720MM WITH OR WITHOUT OPTIONAL DRAWER	MINIMUM 500 X 720mm WITHOUT OPTIONAL DRAWER
	MINIMUM 570 X 720mm WITH OPTIONAL DRAWER









AIR CIRCULATION PIPES

Create air recirculation inside the structure that covers the insert for correct operation. This prevents the appliance from overheating.
To guarantee this, just make one or more openings in the lower and upper parts of the covering.
The following measurements must be respected:

- **LOWER PART (COLD AIR INLET) WITH TOTAL MINIMUM SURFACE 550 CM².**
- **UPPER PART (HOT AIR OUTLET) WITH TOTAL MINIMUM SURFACE 550 CM².**



Reference A

- **Hot convection air 550 cm²**: The heat accumulated inside the covering must be vented to prevent excessive overheating of the insert.

Reference B

- **Forced ventilation:**
  The tangential fan distributes the heat developed by the insert into the environment.

Reference C

- **Room air inlet 550 cm²:**
  To allow air recirculation an air inlet point must be envisioned, which is preferably positioned in the lower part of the structure in order to encourage convection. The air must be withdrawn from the machine's working environment.

THE FLUE OUTLET PIPE MUST ALWAYS MAINTAIN A MINIMUM DISTANCE OF 50 MM FROM INFLAMMABLE PARTS.

Make a hole at the base of the flue (figure 1) for air circulation and to ensure the required combustion air for proper insert combustion.
If it is not possible to make a hole at the centre of the base, make two openings to the sides of the base, equal to the 550cm^2 overall lower inlet (2 x 275cm^2) (See figure 2).



(figure 1)



(figure 2)

In order for the insert to work properly, observe the measurements contained in the *"MINIMUM DIMENSIONS"* when building the chimney that must be made of non-flammable material.
As well as the dimensions of the stove given in the technical features, consider at least 50 mm of air at the back of the insert. (see figure 3)



(figure 3)

To protect from any over-heating, the Comfort P70 and P70h49 is supplied with a probe that analyses the temperature inside the structure and intervenes by reducing the functioning power.

THIS VENTILATION SYSTEM IS TOTALLY INDEPENDENT FROM THE AIR INTAKE FOR COMBUSTION!!

ASSEMBLY WITH SLIDING BASE

Take the sliding base and position it in the pre-existing flue. Use chalk to mark the blocking holes of the base on the flue surface.
Drill 8 mm holes for the steel expansion inserts.
Make a hole measuring 60 mm in line with the air intake.

Remember the power socket on the rear of the insert so that the plug is accessible once installation is completed.
Fix the base using the clamping screws.
Create a flue exhaust and socket connection respecting the points described previously.
Take the insert, tilt it so that the wheels fit into the relative rails, make it run until the flue gas insert is completely inserted into the flue gas conveyor box.



PEDESTAL ASSEMBLY (OPTIONAL):

Position the base in the desired point and use the feet to adjust the desired height (the bolts are positioned in the four external sides of the pedestal in the lower part).
Remember the power socket on the rear of the pedestal so that the plug is accessible once installation is completed.

Fix the pedestal to the floor using strong steel plugs with a diameter of 8 mm.
Fix the sliding base to the frame using bolts.
Connect the flue gas exhaust pipe and the air vent as stated in the previous paragraph.
Take the insert, tilt it so that the wheels fit into the relative rails, make it run until the flue gas auger is completely inserted into the flue gas conveyor box.
Finally open the fire door and use the supplied Allen key to turn the screw at the bottom left corner clockwise.

To understand whether the insert is correctly attached to the base, connect the plug to the socket and make sure the display switches on.



N.B.: If our pedestal is used, a slot must be created in the flue that allows the pellet level in the feed-box to be checked, thus preventing spillage during filling.

MOUNTING THE FRAMES

As standard, the insert has a finishing frame that, as well as finishing, covers the side slot required between the structure and covering.

P70 UPPER FRAME ASSEMBLY:

Simply fit the frame on the relevant pins, as shown in figure 1.

figure 1



P70H49 UPPER FRAME ASSEMBLY:

The upper frame is fitted via 2 screws as shown in figure 2.

figure 2



SIDE FRAME ASSEMBLY FOR P70 AND FOR P70H49:

The side frames are fitted using 2 screws per side as shown in figure 3.



figure 3

THE INSERT MUST OVERLAP THE MARBLE COVERING SURFACE BY AT LEAST 1 CM.

N.B. ANY WOODEN BEAMS LOCATED ABOVE THE INSERT MUST BE PROTECTED WITH NON-INFLAMMABLE MATERIAL.
FRAME ASSEMBLY IS IMPORTANT AS IT ALLOWS CORRECT RECIRCULATION OF THE AIR AND CONSEQUENTLY OPTIMAL PRODUCT OPERATION.

INSERT LOCKING AND RELEASING SAFETY DEVICE

Open the door and turn, using the poker supplied, insert the lockbolt in the corner at the bottom on the left and turn anticlockwise to open (release) or clockwise to close (lock).



OPEN - RELEASED



CLOSED - LOCKED

To understand whether the insert is attached to the base properly, connect the plug to the socket and make sure it works with the supplied remote control.

REMOVING THE INSERT AND LOADING PELLETS

The extraction of the insert allows pellets to be loaded inside the feed-box and to perform routine maintenance, (cleaning the ash pipe at the end of the year) or special maintenance (replacement of mechanical parts if the product should break).
Follow this procedure to extract the insert:
Open the door and turn the lockbolt in the corner at the bottom on the left anticlockwise.
Using the relevant pokers, pull the machine towards yourself until it blocks automatically.

THE INSERT MUST ONLY BE EXTRACTED WHEN THE MACHINE IS SWITCHED OFF AND COMPLETELY COLD!





PELLETS

The pellet used must comply with the features described by Standards:

- **EN PLUS - UNI EN 16961 - 2 class A1 or A2**
- **Ö-NORM M 7135**
- **DIN PLUS 51731**

Extraflame recommends using pellets with a diameter of 6mm with its products.

THE USE OF POOR QUALITY PELLETS OR ANY OTHER MATERIAL DAMAGES THE FUNCTIONS OF YOUR STOVE AND CAN VOID THE WARRANTY AND THE ANNEXED RESPONSIBILITY OF THE MANUFACTURER.
TO GUARANTEE COMBUSTION WITHOUT PROBLEMS, THE PELLETS MUST BE KEPT IN A DRY PLACE.

FRONT PELLET FEEDING KIT (OPTIONAL)

The optional pellet feeding kit allows pellets to be fed into the feed-box from the front without having to extract the insert (operation that requires machine switch-off).



Further information on the accessories is available on the website: www.extraflame.it/support, in the category "accessories".

IN THE EVENT OF INSTALLATION WITH FEEDING KIT (OPTIONAL) THE MACHINE MUST NOT BE EXTRACTED.

CONTROL PANEL



DISPLAY ICONS KEY

	Indicates the receipt of the radio signal On = during radio communication Off = no radio communication Fixed on = serial input disabled		It indicates weekly programming functioning Indicator on = weekly programming active Indicator off = weekly programming disabled
	It indicates fumes motor operation. Off = fumes motor disabled On = fumes motor active Flashing = breakdown		Indicates the stove modulation On = the stove is working at the set power Flashing = the power at which the stove is working is different to the power set, the stove is modulating (for various reasons)
	It indicates tangential fan operation (where applicable) Off = not working On = working Flashing = motor at minimum	+	Indicates the presence of an alarm. Triangle On + 1 flashing key: Indicates the presence of an alarm
	It indicates pellet feed motor operation Off = pellet feed motor disabled On = pellet feed motor active		
	Indicates the compensation function Off = the function is disabled On = the function is active		Indicates the room temperature status Off = the T° read by the probe is above the set temperature On = the T° read by the probe is below the set temperature

	Indicates the contact of the external additional thermostat			
	Contact closed:	the contact of the external additional thermostat is closed and the STBY function is disabled	Flashing with closed contact:	the contact of the external additional thermostat is closed and the STBY function is active
	Contact open:	the contact of the external additional thermostat is open and the STBY function is disabled	Flashing with open contact:	the contact of the external additional thermostat is open and the STBY function is active

GENERAL MENU



*** NOT USED**

BASIC INSTRUCTIONS

The following recommendations must be followed the first times the stove is ignited:

- Faint smells may be produced due to the drying of the paints and silicones used. Do not remain in the environment for long periods.
- Do not touch the surfaces as they could still be unstable.
- Air the room well several times.
- The hardening of the surfaces is terminated after several heating processes.
- This appliance must not be used to burn waste.

Before lighting the stove, the following points must be verified:

- The hydraulic system must be completed in compliance with the guidelines of the regulations and the manual.
- The tank must be full of pellets
- The combustion chamber must be clean
- The burn pot must be completely free and clean
- Check the hermetic closure of the fire door and the ash drawer
- Check that the power supply cable is connected correctly
- The bipolar switch in the rear right part must be positioned on 1.

IT IS FORBIDDEN TO USE THE APPLIANCE WITHOUT THE DIVIDER AND/ OR GLASS PROTECTION (SEE THE FIGURE TO THE SIDE).
ITS REMOVAL JEOPARDISES THE SAFETY OF THE PRODUCT AND IMMEDIATELY VOIDS THE WARRANTY PERIOD.
IN THE EVENT OF WEAR OR DETERIORATION CONTACT THE ASSISTANCE SERVICE TO REPLACE THE PART
(THE REPLACEMENT IS NOT COVERED BY THE PRODUCT WARRANTY AS IT IS A PART SUBJECT TO WEAR).



THE REMOTE CONTROL

All that can normally be implemented through the LCD can be adjusted using the remote control.
The table below provides a detailed description of the various functions:

1	**ON / OFF**	Pressing the key for three seconds, the stove will switch on or off
2	**POWER INCREASE**	Pressing the key will increase the operating power
3	**POWER DECREASE**	Pressing the key will decrease the operating power
4	**T° INCREASE**	The temperature setting can be increased by pressing this key
5	**T° DECREASE**	The set temperature can be decreased by pressing this key
6	**ENABLE / DISABLE CHRONO**	Pressing the key once will enable or disable the chrono
7	**DELAYED SWITCH-OFF ENABLING**	The delayed switch-off can be set by pressing this key. For example, if the stove is set to switch-off in an hour, it shall switch-off automatically once the set time elapses, displaying the countdown every minute for delayed automatic shutdown.
8	**MENU**	This key allows to access the user and technical menu (the technical menu is reserved for assistance)
9	**INCREASE**	The temperature setting can be increased by pressing this key
10	**ESC KEY**	The key allows the user to exit any program or display and returns to the main menu without saving the data
11	**BACK**	The key returns to the display of the various menus
12	**CONFIRMATION KEY**	This key confirms the adjustments made during the user menu programming phase
13	**FORWARD**	The key allows to go forward in the various menus
14	**ENABLE FUNCTION F1**	Pre-set key for future applications
15	**DECREASE**	The key decreases the value to be set
16	**STOVE STATUS**	Pressing this key will display the general status of the stove

Important note: the numbers shown on the remote control are purely indicative and are not present on the remote control supplied with the product.

TYPE AND REPLACEMENT OF BATTERIES

The batteries are housed in the lower part of the remote control.
To replace them, remove the battery holder (as indicated in the figure at the back of the remote control), remove or insert the battery according to the symbol on the remote control and on the battery itself.



For operation, 1 CR2025, 3V lithium buffer battery is required.

The batteries used contain metals harmful for the environment. They must therefore be disposed of separately in appropriate containers.

If the remote control is off because it has no batteries, the stove can be controlled from the control panel on top of it.
While replacing the battery, pay attention to the polarity by observing the symbol on the inside compartment of the remote control.

COMMISSIONING SETTINGS

Once the power cable at the back of the stove has been connected, move the switch, also located on the back, to (I).
The switch at the back of the stove powers the stove board.
The stove remains off and a first screen appears on the panel reading OFF.

ADJUSTING TIME, DAY, MONTH AND YEAR

Set clock allows to adjust the time and date

CONTROLS PROCEDURE

- Press key 6 and **SET CLOCK** will appear.
- Confirm using key 6.
- Use keys 4 and 5 to select the day.
- Proceed by pressing key 2.
- With the same procedure, use keys 4 or 5 to set and key 2 to move forward, to adjust the hours, minutes, day, month and year
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.

SET CLOCK	
DAY	MON, TUE, WED, ...SUN
HOURS	0...23
MINUTES	00...59
DATE	1...31
MONTH	1...12
YEAR	00...99

ADJUSTING LANGUAGE

It is possible to select the preferred language to display the various messages.

CONTROLS PROCEDURE

- Press key 6 and **SET CLOCK** will appear.
- Press key 2 until **SET LANGUAGE** appears.
- Confirm using key 6.
- Select the language using key 4 or 5.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.

SET LANGUAGE	
LANGUAGE	ITALIAN
	ENGLISH
	GERMAN
	FRENCH
	SPANISH

NO IGNITION

FIRST IGNITION COULD EVEN FAIL AS THE AUGER IS EMPTY AND IS NOT ALWAYS ABLE TO LOAD THE BURN POT WITH THE REQUIRED AMOUNT OF PELLETS ON TIME TO REGULARLY START THE FLAME.
IF THE PROBLEM OCCURS AFTER ONLY A FEW MONTHS WORKING, CHECK THAT ROUTINE CLEANING STATED IN THE STOVE BOOKLET, HAS BEEN CARRIED OUT CORRECTLY.

CLEAN CHECK UP 1 - 2

IN THE EVENT THE "ALL NO FLUSSO - ALL CLEAN CHECK UP " ALARM IS TRIGGERED, MAKE SURE THAT THE BOTTOM OF THE BURN POT IS FREE OF RESIDUES OR SCALES. THE HOLES AT THE BOTTOM MUST BE COMPLETELY FREE TO GUARANTEE CORRECT COMBUSTION. ONE CAN USE THE FUNCTION "PELLET FEED ADJUSTMENT" TO ADJUST COMBUSTION ACCORDING TO THE DESCRIBED REQUIREMENTS. IF THE ALARM PERSISTS AND THE ABOVE LISTED CONDITIONS HAVE BEEN CHECKED, CONTACT THE QUALIFIED AFTER-SALES ASSISTANCE CENTRE.



OPERATION AND LOGIC



IGNITION
Once the points listed previously have been checked, press key 1 for three seconds to ignite the stove. 15 minutes are given for the ignition stage, after ignition and once the control temperature has been reached, the
stove interrupts the ignition phase and switches to the START-UP mode.

STARTING
During the start-up stage, the stove stabilises combustion, increasing it gradually, to then start ventilation and switch to the WORK mode.

WORK
During the work stage, the stove reaches the set power and works to reach the set room temperature. See following item.

THERMOSTAT SETTING ADJUSTMENT
The room temperature setting can be set using buttons 4 and 5, from Low-07 to 40°C -Hot

LOW - HOT
If the temperature setting is on "Low" (set below the 7°C threshold) the stove will always function at minimum.
If the setting is on "Hot" (set above the 40°C threshold) the stove will not modulate, always functioning and only at the set power.

ADJUSTING POWER SETTING
The power setting features 5 operating levels, via button 5, (access) 1 and 2 (adjustment).
Power 1 = minimum level - Power 5 = maximum level.

WORK WITH ROOM PROBE (STANDARD)
The appliance controls the room temperature via a probe fitted on the appliance.
Once the the set temperature has been reached, it will automatically go to minimum or switch off activating the **Stand by** function, reducing pellet consumption to a minimum.

By default the **STBY** function is always set on **OFF** (light on).
For its activation and logic, follow the indications on the next page, chapter: **Stand by.**

BURN POT CLEANING
During the work stage, the stove has an internal counter which cleans the burn pot after a set amount of time.
This stage will be shown on the display, it will bring the stove to a lower power level and will increase the fumes motor for a programmed amount of time.
When the cleaning stage is finished, the stove will continue its work, going back to the selected power level.

SWITCH-OFF
Press key 1 for three seconds.
When the operation has been performed, the appliance automatically enters the switch- off phase, blocking the supply of pellets.
The fumes motor and the hot air ventilation motor will remain on until the temperature of the stove has dropped below the factory parameters.

RE-IGNITION
The stove can only be re-ignited if the flue gas temperature has lowered and the preset timer has been reset to zero.

DO NOT USE ANY INFLAMMABLE LIQUIDS FOR IGNITION!
DO NOT ALLOW THE BAG OF PELLETS TO COME INTO CONTACT WITH THE BOILING HOT STOVE DURING THE FILLING PHASE!
IN THE EVENT OF CONTINUOUS NO IGNITION, CONTACT AN AUTHORISED TECHNICIAN.

ADDITIONAL THERMOSTAT (OPTIONAL)

The appliance can control the room temperature using an additional external thermostat (optional).
After ignition (pressing key 1 or via chrono mode), the stove will work to reach the setting set on the thermostat, displaying **WORK** (**contact closed**). The standard room probe is automatically ignored.
When the room temperature has been reached (**open contact**) the stove will go to minimum, displaying **MODULATE.**

TO INSTALL AND ENABLE IT:

- A mechanical or digital thermostat is required.
- Remove the plug from the socket.
- Referring to the figure to the side, connect the two thermostat wires (dry contact - not 220 V!) on the relative terminals at the back of the machine, one is red and the other one is black.
- Power the stove.
- Press key 5, setting the temperature on **LOW**.



The stove is now configured correctly.
It will work controlling the additional external thermostat.

INSTALLATION MUST BE PERFORMED BY QUALIFIED STAFF AND/OR THE MANUFACTURER'S TECHNICAL AFTER-SALES ASSISTANCE

THERE ARE TWO STOVE OPERATING MODES, WHICH ARE DIFFERENT ACCORDING TO THE STAND- BY FUNCTION. SEE "STAND - BY" CHAPTER.

USER MENU

DISPLAY

This menu allows to adjust the brightness of the display. By default set on OFF, the display and keys backlight will switch off after a preset delay.
The back light will go on as soon as a key is pressed or if an alarm should be triggered in the machine.
By setting between 10 and 31, adjust the lighting intensity of the display (10 = minimum brightness, 31 = maximum brightness) and the backlight always stays active.

CONTROLS PROCEDURE
- Press key 6 and **SET CLOCK** will appear.
- Press key 2 several times until **USER** is displayed.
- Press key 6.
- "**DISPLAY**" will appear.
- Use keys 4 -5 to select the brightness of the display.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.

PELLET FEED ADJUSTMENT

The following menu allows to adjust the percentage of pellet feed.
If the stove has functioning problems owing to the quantity of pellets, adjust pellet feeding directly from the control board.

The problems correlated to the amount of fuel can be divided into 2 categories:

NO FUEL:

- the stove can never develop a suitable flame, tending to remain very low even at high powers.
- at minimum power the stove tends to almost switch-off taking the stove into "**NO PELLETS**" alarm condition.
- when the stove displays the "**NO PELLETS**" alarm, there may be non-burned pellets inside the burn pot.

EXCESS FUEL:

- the stove develops a very high flame even at low power.
- the panoramic glass is very dirty, obscuring it almost totally.
- the burn pot tends to become encrusted, blocking the holes for air intake due to the excessive pellet feed, as it is only burned partially.

The adjustment to be performed is in percentage. Therefore changing this parameter will lead to a proportional variation of all stove feeding speeds. Feeding is from -20% to +30%.

Follow the procedure on the display to perform the procedure:

CONTROLS PROCEDURE
- Press key 6 and **SET CLOCK** will appear.
- Press key 2 several times until **USER** is displayed.
- Press key 6.
- "**DISPLAY**" will appear.
- Press key 2 until "**PELLET**" appears.
- Use keys 4 - increase 5 to(4) or decrease (5) the load during the WORK stage.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.

V1- AIR

The menu allows to adjust the speed of the front fan in percentage.

CONTROLS PROCEDURE
- Press key 6 and **SET CLOCK** will appear.
- Press key 2 several times until **USER** is displayed.
- Press key 6.
- "**DISPLAY**" will appear.
- Press key 2 until "**V1 AIR**" appears.
- Use keys 4 -5 to increase (4) or decrease (5)
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.



STAND BY

- STAND - BY WITH DIGITAL THERMOSTAT (STANDARD)

STBY FUNCTION SET AT ON

If the Stby function is active (ON), when the stove reaches the set room temperature and exceeds it by 2°C, it will switch off after a default delay time, displaying stand - by.
When the room temperature is 2°C lower than the setting and once the stove has cooled, it will start to work again at the set power and displaying work.

STBY FUNCTION SET AT OFF (DEFAULT SETTING)

If the Stby function is not active (OFF), if the stove reaches the set room temperature, it will go to minimum, modulating and displaying modulate. When the room temperature is below the setting, it will start to work again at the set power and displaying work.

- STAND - BY WITH ADDITIONAL THERMOSTAT

The STBY function is used if immediate stove switch-off is required when the set temperature has been reached.
By default the STBY function is always set on OFF (light on).

- **STBY FUNCTION SET AT OFF** (DEFAULT SETTING)
  If the STBY function is not active (OFF), if the stove reaches the set room temperature, it will go to minimum, modulating and displaying **MODULATE**. When the room temperature is below the setting, it will start to work again at the set power and displaying **WORK**.

- **STBY FUNCTION SET AT ON**
  When the STBY function is activated (ON), the stove, upon reaching the set room temperature and exceeding it by 2°C, will switch off after a pre-set default delay, displaying **STAND - BY**.
  When the room temperature is 2°C lower than the setting, the stove will start to work again at the set power displaying WORK.

CONTROLS PROCEDURE
- Press key 6 and **SET CLOCK** will appear.
- Press key 2 several times to reach **SET USER.**
- Confirm using key 6.
- Press key 2 several times to reach **STAND-BY.**
- Using key 4 or 5 select at ON.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.

The STAND-BY function is active

KEYS LOCKED

The menu allows to lock the display keys (like with mobile phones).
With the function engaged, every time a key is pressed, "**KEYS LOCKED**" will appear.

CONTROLS PROCEDURE
- Press key 6 and **SET CLOCK** will appear.
- Press key 2 several times until **USER** is displayed.
- Press key 6.
- "**DISPLAY**" will appear.
- Press key 2 until "**KEYS LOCKED**" appears.
- Use keys 4 -5 to select enable/disable.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.

ONCE THE FUNCTION IS ACTIVATED, USE KEYS 1 AND 5 AT THE SAME TIME TO LOCK OR UNLOCK THE KEYBOARD

V2 - AIR
- NOT USED

The menu allows to adjust the speed of the ducted fan in percentage.

CONTROLS PROCEDURE
- Press key 6 and **SET CLOCK** will appear.
- Press key 2 several times until **USER** is displayed.
- Press key 6.
- "**DISPLAY**" will appear.
- Press key 2 until "**V2 AIR**" appears.
- Use keys 4 -5 to increase (4) or decrease (5)
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.



RESET

Allows to reset all values modifiable by the user to the default values. The modified data is the following:

CONTROLS PROCEDURE
- Press key 6 and **SET CLOCK** will appear.
- Press key 2 several times until **USER** is displayed.
- Press key 6.
- "**DISPLAY**" will appear.
- Press key 2 until "**RESET**" appears.
- Press keys 4-5 to select **ON** and press key 6.
- "**DONE**" will appear on the display to confirm

- SET TEMPERATURE = 35°C
- SET POWER = 5
- ENABLE CHRONO = OFF
- START PRG1=OFF
- STOP PRG1 = OFF
- MONDAY PRG1 = OFF
- .....all chrono parameters OFF
- PELLET = 00%
- STAND BY = OFF
- V1 AIR = 0 %
- V2 AIR = 0 %

CHRONO

The chrono allows to program 4 time spans within a day to use every day of the week.
The switch-on and switch-off time can be set in every time slot, along with the days of use of the programmed time slot and the desired room temperature (07 - 40°C).

RECOMMENDATIONS
The ignition and switch-off times must be within the arc of one day, from 0 to 24 and not over several days:
Before using the chrono function, set the current day and time. Therefore check that the points listed in the "*Set clock*" sub-chapter have been followed, so that the chrono function works. Aside from programming it, activate it as well.

EXAMPLE:

SWITCH-ON TIME 07:00 **SWITCH-OFF TIME 18:00**	**CORRECT**
IGNITION 22:00 **SWITCH-OFF 05:00**	**INCORRECT**

PROGRAMMING EXAMPLE

Let's suppose that the weekly Programmer function is to be used and 4 time slots are to be used in the following way:
1st time slot: from 08:00 to 12:00 every day of the week, with room temperature at 19°C, excluding Saturday and Sunday
2nd time slot: from 15:00 to 22:00 only on Saturday and Sunday, with room temperature setting of 21°C

CONTROLS PROCEDURE:

SET CLOCK

Press key 6 once, SET CLOCK will appear.
Press key 2 until **SET CHRONO** appears

CHRONO SETTING

ENABLE CHRONO

Press key 6, **ENABLE CHRONO** and **OFF** will appear.
Press key 4 to activate or disable the **CHRONO** function. Select **ON**.

ENABLE CHRONO ON

Press key 6 to confirm and continue programming.

START PRG1 OFF will appear.

START PRG1 OFF

1ST TIME SLOT SWITCH-ON

Use keys 4 - 5 to enter the time "**08:00**", which corresponds to the switch-on time of the 1st time slot.
To confirm and continue programming, press button 6. Press button 3 to go back to the previous parameter.

START PRG1 08:00

1ST TIME SLOT SWITCH-OFF

Use keys 4 - 5 to enter the time "**12:00**", which corresponds to the switch-off time of the 1st time slot.
To confirm and continue programming, press button 6. Press button 3 to go back to the previous parameter.

STOP PRG1 12:00

ENABLING THE 1ST TIME SLOT DAYS

To enable/ disable the days use keys 4 and 5; key 2 and 3 to scroll the various days, the day of the week will appear, followed by **OFF**
select from Monday to Friday on **ON**, excluding Saturday and Sunday (OFF)

MONDAY..PRG1 ON-OFF

1ST TIME SLOT H2O TEMPERATURE SETTING

Press key 6 to confirm and continue programming.
Using buttons 4 - 5 select the desired temperature.
(Low -07 - 40°C Hot)

To confirm and proceed press key 6.

SET PRG1 19°C

2ND TIME SLOT SWITCH-ON*

At this point, the second time slot must be programmed.

The sequence to be followed is the same and is repeated as per the 1ST TIME SLOT SWITCH-ON.

START PRG2 OFF

*2ND TIME SLOT SWITCH-ON
At this point, the second time slot must be programmed.
The sequence to be followed is the same and is repeated as per the 1ST TIME SLOT SWITCH-ON.
On this occasion simply enter the time, for example start at 15:00 and Stop at 22:00 and to activate the days Saturday and Sunday by setting them at "ON".

WHEN THE WEEKLY PROGRAMMER IS ACTIVE, A BOX OF THE RELATIVE ICON WILL APPEAR ON THE CONTROL BOARD.

CLEANING UNDER USER'S RESPONSIBILITY

The images are for illustration purposes.

DAILY

Burn pot:

Remove the burn pot from the relevant compartment and free the holes using the special poker supplied, remove the ash from the burn pot using a vacuum cleaner.
Vacuum the ash deposited in the brazier compartment.





Scrapers :

The heat exchangers must only be cleaned when the stove is cold!
Cleaning the heat exchangers allows to ensure constant heat output over time.
This type of maintenance must be performed at least once a day. To do this, just use the relevant scrapers positioned in the upper part of the stove, making upward movements and vice versa several times.



WEEKLY

Cleaning the ash drawer:

Empty the ash drawer every week or when required.
It is recommended to remove the ash in the combustion chamber at least once a week using a suitable vacuum cleaner.



CLEANING UNDER USER'S RESPONSIBILITY

The images are for illustration purposes.

MONTHLY

Cleaning the heat exchanger: The heat exchangers chamber must be cleaned every month as the soot deposited on the rear of the cast iron hearth wall blocks the regular flow of fumes.
To access the heat exchangers, remove the front piece from the hearth wall, following the operations described below:
Remove the burn pot from its seat
Turn the lockbolt by 90° clockwise manually.



Take the removable cast iron part with your hands, lift upwards and then pull it out of the combustion chamber by pulling it towards yourself, paying attention to the 2 cast iron hooks at the bottom.

Remove the two cast iron parts at the base of the burn pot by pushing them towards each other.





Once the front hearth wall has been removed, remove the two side cast iron parts, undoing the screw highlighted in the picture below.
Then use the poker supplied to remove and scrape the soot deposited between the pipe unit and only then use a vacuum cleaner to fully remove the ash.





When cleaning is complete, re-position the extractable cast iron with the opposite movement used to remove it. When the hearth wall has been positioned, turn the lockbolt to put it back in its original position.

ROUTINE MAINTENANCE

In order to guarantee proper functioning and safety of the device, the operations indicated below must be performed every season or more often when necessary.

DOOR, ASH DRAWER AND BURN POT GASKETS
The gaskets ensure the tightness of the stove and its consequent proper operation.
They must be checked periodically: in the event they are worn or damaged they must be replaced immediately.
These operations must be carried out by a qualified technician.

CONNECTION TO THE FLUE
Vacuum and clean the pipe that leads to the flue yearly or whenever necessary. If there are horizontal sections, the residues must be removed before they can obstruct flue passage.

ALWAYS FOLLOW THE INSTRUCTIONS IN MAXIMUM SAFETY CONDITIONS!

- **WITH THE STOVE FULLY COOLED DOWN, SWITCHED OFF AND DISCONNECTED FROM THE MAINS ELECTRICITY.**
- **FAILURE TO CLEAN JEOPARDISES SAFETY!**
- **FOR PROPER OPERATION, THE STOVE MUST UNDERGO ROUTINE MAINTENANCE BY A QUALIFIED TECHNICIAN, AT LEAST ONCE A YEAR.**
- **IF THE POWER SUPPLY CABLE IS DAMAGED, IT MUST BE REPLACED BY THE AFTER-SALES SERVICE OR BY A SIMILARLY QUALIFIED PERSON, SO AS TO AVOID ALL RISKS.**

A	Fumes motor (disassembly and cleaning and fumes pipe), new silicone in required points	☑
B	Inspection of gaskets and door (replace them and apply silicone where required)	☑
C	Combustion chamber (total cleaning of the entire chamber) and ignition plug holder tube cleaning.	☑





D	Tank (complete emptying and cleaning).	☑
E	Room air fan disassembly and removal of dust and any pellet debris	☑
F	Air intake pipe inspection and of flow sensor cleaning	☑

DISPLAYS	
DISPLAY	**REASON**
OFF	Stove off
START	The start phase is in progress
PELLET FEEDING	Pellet feeding during the ignition phase is in progress
IGNITION	The ignition phase is in progress
START-UP	The start phase is in progress
WORK	The normal work phase is in progress
MODULATION	The stove is modulating
BURN POT CLEANING	The automatic burn pot cleaning is in progress.
FINAL CLEANING	When the stove is switched-off, final cleaning is in progress. The final cleaning phase lasts about 10 minutes.
STAND BY	Stove off due to temperature reached and in stand-by for re-ignition.
EXT STAND BY	Stove off due to an external thermostat, in stand-by for re-ignition
COOLING STAND-BY	A new ignition is attempted when the stove has just been switched off. When the stove switches off, one must wait for the complete shutdown of the fumes motor, then clean the burn pot. The stove can only be re-ignited when these operations have been performed.
COOLING STAND-BY BLACK OUT	The stove is cooling due to black out
LOW	Room thermostat set at minimum value. In this mode the stove only works at 1st power independently from the power set. To exit this function just raise the room temperature using button 4 and then key 2.
HOT	Room thermostat set at maximum value. The stove works at the set speed, without ever modulating. To exit this function just lower the set temperature using button 4 and then key 1.
PELLETS LOW	The "PELLETS LOW" message combined with key 1 flashing slowly indicates that the pellets tank is at minimum. With the machine switched off and fully cooled down, load the pellets tank.

ALARMS		
DISPLAY	**EXPLANATION**	**SOLUTION**
	The fixed triangle on the display and key 1 flashing slowly indicate the presence of an alarm.	On and flashing: indicates the presence of an alarm The alarm can be reset by pressing button 3 for 3 seconds only if the fumes motor has stopped and if 15 minutes have elapsed from when the alarm was displayed.
ASPIRAT - FAULTY	Fault correlated to the flue gas exhaust motor.	The restoration operations must be carried out by an authorised technician.
FUMES PROBE	Fault correlated to the fumes probe.	The restoration operations must be carried out by an authorised technician.
ALARM FUMES OVERHEATING	The flue gas temperature has exceeded 310°C	Check pellet flow (see "Pellet feed adjustment"). Check that the machine is clean, including the fumes passage. Do not rest cloths on the machine. Other restoration operations must be carried out by an authorised technician.
CLEAN CHECK UP 1 - 2 **(1 = IN START-UP STAGE)** **(2= IN OPERATING STAGE)**	The combustion chamber or burn pot bottom are dirty. The door is not closed correctly. The ash drawer is not closed correctly. The depression sensor is faulty. The flue exhaust pipe is blocked. Incorrect installation	Make sure the holes at the burn pot bottom are completely free. Check cleanliness of the fumes pipe and the combustion chamber. Check hermetic door closure. Check hermetic closure of the ash drawer. Other restoration operations must be carried out by an authorised technician.
DEPR ALARM	The mechanical depression sensor has tripped	Contact after-sales centre
NO IGNITION	The pellet feed-box is empty. Pellet feed calibration inadequate. Incorrect installation	Check for the presence of pellets in the feed-box. Adjust pellet flow (see "Pellet feed adjustment"). Check the procedures described in the "Ignition" chapter. Other restoration operations must be carried out by an authorised technician.
BLACK-OUT NO IGN.	No current during the ignition phase.	Set the stove on OFF using key 1 and repeat the procedure described in the "Ignition" chapter. Other restoration operations must be carried out by an authorised technician.
NO PELLETS	In the work phase, the t° of the flue gases has dropped below default parameters	Check for the presence of pellets in the feed-box. Regulate the pellet flow. Other restoration operations must be carried out by an authorised technician.
COOLING STAND-BY	Attempt to release the alarm with stove still in cooling mode.	Every time the stove displays one of the alarms listed above it will switch-off automatically. The stove will block any alarm unlock attempt during this phase, showing the alarm itself and STAND-BY alternately on the display. The alarm can be reset by pressing button 1 for 3 seconds only if the fumes motor has stopped and if 15 minutes have elapsed from when the alarm was displayed.
DEBIMETER FAULT	Component disconnected or faulty	Contact after-sales assistance
AUGER CONTROL ALARM	Anomalous functioning of pellet feeding	Contact after-sales assistance
AUGER BLOCK	Abnormal functioning of pellet motor	Contact after-sales assistance

WARRANTY CONDITIONS

EXTRAFLAME S.p.A., with offices in via dell'Artigianato 12 Montecchio Precalcino (VI), guarantees this product for 2 (two) YEARS from the date of purchase for manufacture and material faults. The warranty becomes void in the event the defect is not reported to the dealer within two months from the date it was detected.

The responsibility of EXTRAFLAME S.p.A. is limited to the supply of the appliance, which must be installed as per regulations and following the instructions contained in the relevant manuals and booklets provided with the purchased product and in compliance with the laws in force.
Installation must be performed by qualified staff, under the responsibility of the person entrusting him, who will assume complete responsibility for the definitive installation and consequent good functioning of the product installed. EXTRAFLAME S.p.A. cannot be held responsible in the event that these precautions are not be respected.

WARNING
It is essential to carry out the functioning inspection of the product before its completion with the relative masonry finishings (counterhood, external coating, pilasters, wall painting, etc). EXTRAFLAME S.p.A. does not assume any responsibility for any damages and consequent restore expenses of the above finishings even if the same occur following the replacement of malfunctioning parts.

THE WARRANTY IS VALIDATED ON THE CONDITION THAT:

EXTRAFLAME S.p.A. assures that all its products are manufactured with top quality materials and with manufacturing techniques which guarantee total efficiency. If during normal use of the product, defective or malfunctioning parts are detected, the partwill be replaced free of charge, by the dealer who made the sale.

TERRITORIAL EXTENSION OF THE WARRANTY:
Italian territory

VALIDITY
THE WARRANTY IS CONSIDERED VALID ON THE CONDITION THAT:

- The purchaser sends the attached coupon within 8 days from the purchase date, filled-in in all parts. The purchase date must be validated by the possession of a valid fiscal document issued by the dealer.
- The appliance is installed in compliance with the Standards in force on this subject, the instructions contained in the provided manual and by professionally qualified staff.
- The appliance is used as prescribed in the instructions manual provided with all products.
- The warranty certificate has been filled-in and signed by the customer, validated by the dealer.
- The warranty document, filled-in and accompanied by the purchase fiscal document issued by the dealer, must be kept and shown to staff of the EXTRAFLAME S.p.A. Technical After-sales Service in the event of intervention.

THE WARRANTY IS NOT CONSIDERED VALID IN THE FOLLOWING CASES

- The warranty conditions described above have not been respected.
- Installation has not been performed with respect to the Standards in force regarding the provisions described in the manual/book provided with the appliance.
- Negligence of the customer due to lack of or incorrect maintenance of the product.
- Presence of electric and/or hydraulic plants that do not comply with the standards in force.
- Damages deriving from atmospheric, chemical, electro-chemical agents, improper use of the product, modifications and tampering with the product, inefficacy and/or unsuitability of the flue and/or other causes not deriving from the manufacture of the product.
- Combustion of materials not compliant with the types and quantities indicated in the manual/book supplied
- All damages caused by transport. It is therefore recommended to carefully check the goods on receipt, immediately informing the dealer of any damage, making a note on the transport document and on the carrier's copy.
- EXTRAFLAME S.p.A. is not liable for any damage that can, directly or indirectly, affect persons, objects and pets as a consequence of failure to comply with the prescriptions indicated in this manual/book.

ALL PARTICULARS SUBJECT TO NORMAL WEAR ARE NOT COVERED BY WARRANTY:
This category includes:

- The gaskets, all ceramic or toughened glass, coverings and cast iron or Ironker grates, the painted, chrome or gold-plated details, the majolica, the handles and the electric cables.

- Colour variations, crackles and slight size differences of the majolica parts are not a reason for claims, as they are natural features of the materials themselves.
- Parts made of refractory material
- Masonry work
- The system particulars for the production of domestic hot water not supplied by EXTRAFLAME S.p.A. (water products only).
- The heat exchanger is excluded from the warranty unless an adequate anti-condensate circuit which guarantees a minimum return temperature of the appliance of at least 55°C (only water products).

FURTHER CLAUSES:

The warranty also excludes any calibration or regulation interventions of the product in relation to the type of fuel or the type of installation.
The warranty is not extended if particulars are replaced.
No compensation will be paid for the time the product is inefficient.
This warranty is valid only for the purchaser and cannot be transferred.

RECOMMENDED INSPECTION (WITH PAYMENT):

EXTRAFLAME S.p.A. recommends that the functional inspection
of the product is performed by a qualified Technical After-Sales Centre, which will supply all
information for correct use.

WARRANTY INTERVENTIONS

The request for intervention must be sent to the dealer or after sales assistance Centre.
The warranty intervention envisions the repair of the appliance without any charge, as provided by the law in force.

LIABILITY

EXTRAFLAME S.p.A. does not grant any compensation for direct or indirect damage caused or depending on the product.

LAW COURT

The Vicenza Law Court is elected as the competent court for any disputes.

Extraflame®

Riscaldamento a Pellet

EXTRAFLAME S.p.A. Via Dell'Artigianato, 12 36030 - MONTECCHIO PRECALCINO (VI) - ITALY
☏ +39.0445.865911 - 🖷 +39.0445.865912 - ✉ info@extraflame.it - 🖳 www.lanordica-extraflame.com

Extraflame reserves the right to vary the features and data shown in this booklet at any time and without prior notice, in order to improve its products.
This manual cannot be considered as a contract for third parties.

This document is available at *www.extraflame.it/support*